


**ATTACHMENT B: Water Flow Schematic and Outfall Summary for  
Nimbus Salmon & Steelhead Hatchery and American River Trout Hatchery**



⊗ = Sampling Location

(not to scale)

**Outfall Summary**

- 001 – Nimbus Fish Ladder (holding pond overflow ; fresh water, if needed)
- 002 – Nimbus Hatchery Buildings (water used for egg hatching and incubation) and Spawning Deck (water used during egg removal)
- 003 – ARTH rearing ponds
- 004 – Settling Pond Overflow (ARTH rearing ponds; ARTH nursery ponds; Nimbus raceways; fish disease control lab; ARTH hatchery building)
- 005 – Discharge to Settling Pond – All ARTH rearing pond flow is diverted to settling ponds during cleaning or chemical treatment